

Wall Solution EASY COVER PRO

Installation Guide

EASY COVER PRO is a definitive solution for the most demanding wall decoration projects.

Self-adhesive vinyl tiles for walls are suitable for being installed in bathrooms, kitchens, rooms and, in general, any other places at home or commercial premises.

The installation on different surfaces such as wood, gypsum, plasterboard, stone, ceramic or stoneware, among others, can be done due to its exclusive fasten system.

Important: installation is NOT recommended under next circumstances:

- The presence of moisture on walls without being properly treated against this problem with a primer to solve this issue.
- The presence of plaster on wall or badly painted (becoming a flaky wall)
- Those areas continuously exposed to sun or heat source, such as, pipes, heating systems, lightbulbs, limelight, engines...
- Those areas continuously exposed to vapour such as, engine rooms, sauna, etc.
- Exterior surface exposed to weather changes such as, raining, snowing, extreme coldness ($\leq 5\text{ }^{\circ}\text{C}$) or extreme heat ($\leq 30\text{ }^{\circ}\text{C}$) or temperature changes of $10\text{ }^{\circ}\text{C}$ in less than 1 hour.
- Plastic surfaces made of PVC, poly (methyl methacrylate) and plastic derivatives (It is necessary to apply a sealing coating first).

Important: Self-adhesive vinyl tiles for walls must be removed from its envelope and being placed where the tiles are going to be installed 48 hours before its installation.

SURFACE PREPARATION:

Wall solution EASY COVER PRO can be installed directly on mineral tiles (ceramic, stoneware, porcelain), expanding to the following surfaces, after applying a primer:

- Wood (OSB, wood strip, okumen plywood...) It is important to remove any rest of varnish or paint that can be detached once installed the coating.
- Plasterboard
- Metallic surfaces (Aluminum, iron, steel) It is needed to remove paint or varnish first, and applying a properly cover to stabilize the surface.
- Plaster surfaces
- Bases of cement or derivatives

- Other surfaces: contact with your supplier.

The surface must be cleaned, free from oil, dust or other substances that might be detached once tiles installed.

Remove any rest of wallpaper, flaky painting, varnish, etc...

Repair, if necessary, any gap on the surface in order to avoid any slope.

ASSEMBLY INSTRUCTIONS:

EASY COVER PRO is a covering easily installed comparing with other covering. Following our instructions, you will get outstanding results in just a few minutes.

Tools required for installation: spirit level, tape measure, pencil, cutter, gun to apply silicone tubes (in case of installation in water areas).

Before installation: If necessary, remove light keys or other accessories and replace them once the cover is installed. The pipes and other obstacles are easy to solve, making a previous measurement and making the fittings in the plank / tile before its installation.

Steps to follow for installation:

- 1) Clean the wall and remove any nails etc.
- 2) Measure the wall carefully and draw a horizontal line, using the spirit level, on all the walls of the room, marking the center of the wall.
- 3) Repeat the procedure drawing a vertical line on each wall, thereby drawing a cross on all walls.
- 4) Installation of the tiles on each wall should begin from the center of each cross.
- 5) Remove the protective film from the tile and apply a small quantity of V-LINE adhesive on each of the marked areas.
- 6) Carefully stick the tile/plank right in the 90° quarter which has been marked in the center of the wall, gently pressing the edges and the center using the same pressure.
- 7) Lay the next/adjacent tile in the same manner.
- 8) To lay the lower tile/plank, measure the center of the tile and make a small pencil mark. Glue the tile in place.
- 9) Follow the same procedure with the upper tile. Install the rest of the tile/plank on the wall following the pattern explained.
- 10) When you reach the edge of the wall, measure the distance from the last tile/plank to the wall and mark how much of the tile to cut
- 11) In order to cut the tile/plank, draw a line. Put a set square or metal ruler on the line, run a cutter gently along the line about three times.

12) Break the tile/plank into pieces by pressing from the centre out to the opposite edges of the piece and finish off cutting the foam with the cutter.

13) In order to lay the pieces of the top and bottom parts of the wall, measure each one of the tile/plank to be cut, and then follow the cutting instructions previously explained.

Installation in water areas

In case of installation inside the shower, it is mandatory to apply a transparent and anti-mold silicone line around the perimeter of the tile/plank during the installation process, so that the tile/plank are sealed together and the water doesn't seep through the wall.

Recommendations

Save at least 10 % of tile/plank in horizontal position to cover possible future deterioration.

Get a perfect finish with our coordinated profiles for corners and for tile/plank ends.

Do not place heavy objects (clothes racks, lighting fixtures, mirrors ...) directly on the tile/plank. Drill in such a way that fastening accessories, such as screws, reach the rear wall on which the Easy Cover Pro plate is installed.

Maintenance:

In order to protect your EASY COVER PRO wallcovering, we recommend the following:

- Always consult your dealer if you are going to place the product in places that do not appear as recommended.
- Avoid subjecting the coating to extreme temperatures and the continuous action of the sun's rays.
- Do not place the product in open places where the sun or rain can reach it directly.
- Keep indoor relative humidity between 40 % and 60 % all year to prevent the coating is subjected to sudden changes in temperature and humidity.
- Maintain a temperature in the place of installation of between 16 and 22 °C in order to prevent movement of expansion or contraction in the plates.
- The coating surface EASY COVER PRO, which is essentially strong and durable. It does not require additional treatments. No need to be polished, varnished, waxed or brightened because no additional treatment retains its intrinsic and essential properties.
- Do not use abrasive products or containing compounds such as ammonia, solvents or other aggressive agents. Using other cleaners can alter product properties such as brightness or colour. If using others cleaning, perform a preliminary test somewhere inconspicuous the wall.